

# How to Configure Card Enrollment Station

## Preparation

1. The card enrollment station includes DS-K1F100-D8E and DS-K1F180-D8E;
2. Please download the iVMS-4200 Client on Hikvision official website;  
[http://www.hikvision.com/en/Tools\\_84.html](http://www.hikvision.com/en/Tools_84.html)

## Notice

1. In this document, we use DS-K1F100-D8E card enrollment station;
2. In this document, we use V2.7.0.6 iVMS-4200 Client;


### Step 1:

Connect the card enrollment station to computer directly via USB port, it will install driver automatically




### Step 2:

Run iVMS-4200 Client, enter **Access Control** interface;




Add **Organization** and **Person** first;




**Step 3:**

On *Add Person* interface, Click *Card* and + *Add* to enter *Add Card* interface;



**Step 4:**

Click *Set Card Enrollment Station* to enter *Card Enrollment Station* interface, please select correct device type;




**Step 5:**

Select correct *Card No. Type*;

*Normal*: if the communication between card reader and access controller is based on RS485 protocol or Wiegand 34 protocol, please select *Normal*;



*Wiegand*: if the communication between card reader and access controller is based on Wiegand 26 protocol, please select *Wiegand*;



**Step 6:**


Click **Save**;

On **Add Card** interface, click **Read** and swipe card on card enrollment station;




**Step 7:**

Click **Stop Reading** to finish adding card and click **OK** to save it;




**Step 8:**

Click **OK** to save your configuration;



**Step 9:**

You can also click **Modify** to enter **Edit Person** interface, and click and **+ Add** to enter **Add Card** interface, and then back to **Step 4**;



<b>Title:</b>	How to Configure Card Enrollment Station	<b>Version:</b>	v1.0	<b>Date:</b>	12/01/2018
<b>Product:</b>	Access Control Device	<b>Page:</b>	5 of 5		



**First Choice for Security Professionals**

***HIK*VISION Technical Support**